



-Rib Roofing and Siding

K-Rib *Suburban* profile with Dripstop

IMPORTANT PREPARATION AND INSTALLATION INFORMATION READ BEFORE INSTALLATION

INSTRUCTIONS FOR PROPER PREPARATION OF PANELS AND TRIM

For all points of exposure to the outside environment, the recommended length the panel should be prepared is as follows:

Eave Overhang - overhang + 1" *

Panel to Panel Endlaps - length of the lap minus 1/4"

(Endlaps are not recommended - Run panels from eave to ridge if possible)

Ridge Cap Laps - length of lap minus 1/4"

- A.) Lay or stack the panels with DripStop Condensation Control facing up and recommended length of each panel exposed.
- B.) Using a heat gun set at 1200° F, move the gun along the exposed end portion of each panel, heating and fusing the fibers of DripStop membrane.
Hold the heat gun approximately 1" away from the DripStop membrane.
Keep the heat gun in constant motion to avoid overheating one spot so that damage to the panel's finish does not occur.
Do not completely melt the DripStop fabric.
If at lapend, do not extend fusing past the lap.
- C.) Allow panels to cool before installing.
- D.) Install per regular panel installation methods.

** Eaves may be prepared after installation of the panels has been completed.*

Failure to properly prepare panels may result in the DripStop membrane attracting water from the outside which can result in possible leaks, mold or mildew which will ultimately void the panel warranty.



Klauer Manufacturing Company

P.O. Box 59 * Dubuque, Iowa 52004-0059

Phone (563) 582-7201 * Fax (563) 582-2022

www.klauer.com

